

1700-AT780

LEDWISE®



SP ECO KIT

CREE XPG3

INSTALLING/REPLACING THE BATTERY

Unscrew the tail cap of the flashlight anti-clockwise to open it. Install a 16340 Li-Ion battery into the smaller device and a 18650 Li-Ion battery into the larger device, so that the positive polarity (+) of the battery points towards the head of the head. Screw the tail cap back to its place. The flashlight is now ready to use. A CR123 battery can be used in the smaller model, but it does not provide maximum light output. Never use the magnetic charger when using a CR123 battery.

ADJUSTING THE LIGHT OUTPUT

Press the main switch once: 40% light output. Press the main switch two times: 10% light output. Press the switch for a longer time to 100% light

output, which will continue for 40 seconds or until the switch is pressed again. Double-click to turn on the strobe/flash mode. Press the button again to leave the mode.

CHARGING

Connect the magnetic end of the USB charger to the tail of the flashlight, and connect the USB connector to its dedicated power source. The indicator on the magnetic charger turns red when the device is charging. When charging is complete, the light turns blue.

CAUTION

Never look directly into a bright light source, and never point it at other people's eyes. Doing so may cause eye damage. The strobe/flash mode might cause epileptic seizures in susceptible

people, so use it carefully. Use only batteries recommended by the manufacturer. Never charge the device with the magnetic charger if you are unsure whether the flashlight is compatible with it. Never try to disassemble the flashlight.

STORAGE/MAINTENANCE

Store the flashlight in a dry and well-ventilated space. Unscrew the tail cap half a turn, so that the light does not turn on when you press the main switch. Use a cloth and water or a mild detergent for cleaning. Be sure to clean the magnetic charger contacts regularly.



www.thelights.fi

Importer:
Startax Finland Oy
www.startax.net



Made in China